



## RUELCO Stock List

Part No : 0-013-0B0  
Part No : 10-013-0A0(MP2 RELAY),  
Part No : 10-013-0B0  
Part No : 103-2410R  
Part No : 10A1-2B200  
Part No : 10A1-2B2P  
Part No : 1103-2410R  
Part No : 12A1-8G200  
Part No : 12AI  
Part No : 2000-6000  
Part No : 2102-37-158  
Part No : 2102-37-168  
Part No : 2102-37-183  
Part No : 2102-37-210  
Part No : 2102-37-283  
Part No : 250-3000  
Part No : 3/8 "MNPT  
Part No : 300-10000PSI  
Part No : 41-008-0A0  
Part No : 41-008-0A0 - 4202N2R000  
Part No : 41-008-0A0 - 4HL2N2R000  
Part No : 41-012-000  
Part No : 41-012-000 - 4202N2R000  
Part No : 41-012-000 - 4HL2N2R000  
Part No : 41-013-000  
Part No : 41-013-000 - 4202N2R000

Part No : 41-013-000 - 4HL2N2R000  
Part No : 41-014-000  
Part No : 41-014-000 - 4202N2R000  
Part No : 41-014-000 - 4HL2N2R000  
Part No : 41-016-0B0  
Part No : 42-003- 0B0  
Part No : 42-003-0B0 - 4202N2R000  
Part No : 42-003-0B0,SS2  
Part No : 42-004-0A0 - 4202N2R000  
Part No : 42-005-000  
Part No : 42-005-000 - 4202N2R000  
Part No : 42-005-000 - 4HL2N2R000  
Part No : 42-025-000  
Part No : 42-025-000 - 4202N2R000  
Part No : 42-025-000 - 4HL2N2R000  
Part No : 4202-1R000  
Part No : 4202N1R000  
Part No : 4202N2B000  
Part No : 4202N2R000  
Part No : 4222-3R  
Part No : 4H-004-0H0  
Part No : 4H-004-0L0 - 4HL2N2R000  
Part No : 4H-005-0B0  
Part No : 4H-005-0B0 - 4HL2N2R000  
Part No : 4HH2N2B000  
Part No : 4HH2N2R000  
Part No : 4HL2N2B000  
Part No : 4HL2N2R000  
Part No : 5/8"-18 LH  
Part No : 5000-10000  
Part No : 5000-15000PSI  
Part No : 7500-1-G-00F  
Part No : 7500-15000  
Part No : 7500-2-B-00F  
Part No : 7500-2B00F

Part No : 7500-2G00F  
Part No : 7500-2R00F  
Part No : 7500-G-00F  
Part No : 91716 SS PANEL MOUNT RING  
Part No : DUPLEX 2205  
Part No : KIT:REPAIR,#10-013-0A0(MP2 RELAY),  
Part No : MP-2 MANUAL  
Part No : MP-2 MANUAL RESET RELAY  
Part No : PANEL MOUNT NUT  
Part No : Pneumatic Pressure Switch Spring  
Part No : RB-1  
Part No : RB-1 UNIVERSAL CONTROL VALVE  
Part No : RD-1 2  
Part No : RD-1 2-WAY DUMP VALVE - NO OVERRIDE  
Part No : RD-1/RD-H  
Part No : REPAIR KIT FOR RD-1/RD-H  
Part No : RGM 268915129 - SN 3 F  
Part No : RUELCO MP-2  
Part No : RUELCO MP-2 MANUAL RESET RELAY H  
Part No : SN 5 FL PROTECTION  
Part No : SS PANEL MOUNT RING  
Part No : SS-2  
Part No : SS-2 4202 BLUE  
Part No : SS-2 4202 N2B000 200 to 750 psi  
Part No : SS-2 4202 N2R000 500 to 1500 psi  
Part No : SS-2 4202 Parts of the Tube  
Part No : SS-2 4202 Piston 1.25 "/0.50"  
Part No : SS-2 4202 Piston Ring for 0.5 "  
Part No : SS-2 4202 Plate Spring  
Part No : SS-2 4202 RED  
Part No : SS-2 4202 Reel for SS-2  
Part No : SS-2 4202 Repair Kit item 17  
Part No : SS-2 4202 Ring for 1.25  
Part No : SS-2 4202 SILVER  
Part No : SS-2 4202 Shaft Ring

Part No : SS-2 PNEUMATIC PRESSURE SWITCH

Part No : SS-2, 4202-1R000

Part No : SS-H 4HH2 BLUE

Part No : SS-H 4HH2 Parts of the Tube

Part No : SS-H 4HH2 Backrest

Part No : SS-H 4HH2 Lower sleeve ring

Part No : SS-H 4HH2 N2B000 200 to 750 psi

Part No : SS-H 4HH2 N2R000 500 to 1500 psi

Part No : SS-H 4HH2 Piston 1.25 "/0.50"

Part No : SS-H 4HH2 Piston ring for 0.5 "

Part No : SS-H 4HH2 Plate Spring

Part No : SS-H 4HH2 RED

Part No : SS-H 4HH2 Reel

Part No : SS-H 4HH2 Repair kit

Part No : SS-H 4HH2 Ring for 1.25 "piston

Part No : SS-H 4HH2 SILVER

Part No : SS-H 4HH2 Shaft Ring

Part No : SS-H 4HH2 Upper sleeve ring

Part No : SS-H 4HL2

Part No : SS-H 4HL2 Axle Ring

Part No : SS-H 4HL2 BLUE

Part No : SS-H 4HL2 Backrest

Part No : SS-H 4HL2 Lower sleeve ring

Part No : SS-H 4HL2 N2B000

Part No : SS-H 4HL2 N2R000 500 to 1500 psi

Part No : SS-H 4HL2 Piston 1.25 "/0.50"

Part No : SS-H 4HL2 Piston ring for 0.5 "

Part No : SS-H 4HL2 Plate Spring

Part No : SS-H 4HL2 RED

Part No : SS-H 4HL2 Reel

Part No : SS-H 4HL2 Repair kit

Part No : SS-H 4HL2 Ring for 1.25 "piston

Part No : SS-H 4HL2 SILVER

Part No : SS-H 4HL2 Sleeve upper ring